

เข้า Controller

1. คลิก Configure
2. เลือก Network
3. เลือกแท็บ Controller
4. ใส่ IP Controller ที่ต้องการ
5. Default Gateway และ DNS ใส่ IP ของ Mikrotik

iNSTAT KIOSK

Dashboard
Coupons
Report
Configure
System
Network
Mikrotik
Printer
Maintenance
Logout

Controller Syslog

Input the Controller IP, SubnetMask, DNS and default gateway

4 IP Address: 192.168.234.3
IP address for controller, for example 192.168.234.3

Subnet Mask: 255.255.255.0
Subnetmask, for example 255.255.255.0

5 Default Gateway: 192.168.234.1
IP of the default gateway for this controller, for example 192.168.234.1

DNS (Confirm): 192.168.234.1
IP of the DNS, for example 192.168.234.1

Cancel Save **6**

6. เมื่อกำหนดตามที่ต้องการกด Save
7. กด Confirm ยืนยันอีกครั้ง

Controller configuration

Are you sure to change the network configuration?
You must restart the controller for it to take effect.

Cancel Confirm **7**

9. กดปุ่ม Restart อีกครั้ง

Controller Mikrotik

9 Restart: Restart Mikrotik, it will temporarily disconnect data traffic.

Shutdown: When the power is turned off, the user will not be able to use it until the power is turned on again. back on.

10. กด Confirm ยืนยันอีกครั้ง

Restart

Restart the system to refresh the device. During restart, users will not be able to log in for approximately 5 minutes.

Cancel Confirm **10**

8. กดปุ่ม Restart เพื่อ Update

Controller Syslog

The controller was successfully updated. Restart **8**