

วิธีกำหนดความเร็ว (Profile Limitation)

Profile Limitations : เป็นการกำหนดความเร็ว หรือข้อจำกัดอื่นๆ และนำไปใช้ร่วมกับ profile ที่เป็นการกำหนดระยะเวลาใช้งาน เพื่อให้ user ที่ใช้ profile นั้นเป็นไปตามเงื่อนไขที่ต้องการ

ตัวอย่าง กำหนดความเร็วของ Profile: Day_1 ให้ใช้ความเร็วได้ไม่เกิน 10Mbps

1. เลือกเมนู User Manager
2. เลือกแท็บ Profile Limitations
3. กดปุ่ม Add New

Instant-Hotspot

Profile Limitations

Add New

Profile	Limitation	From Time	Till Time
Day_2	50Mbps/50Mbps	00:00:00	23:59:59

4. เลือก Profile ที่ต้องการ
5. เลือก Limitation ที่ต้องการ
6. กดปุ่ม OK

Profile: Day_1

Limitation: 10M

From Time: 00:00:00

Till Time: 23:59:59

Weekdays: Sun Mon Tue Wed Thu Fri Sat

Cancel Apply OK

Instant-Hotspot

Profile Limitations

Add New

Profile	Limitation	From Time	Till Time
Day_1	10M	00:00:00	23:59:59
Day_2	50Mbps/50Mbps	00:00:00	23:59:59

ดังนั้น User ที่ใช้ Profile:Day_1 จะถูกกำหนดให้ใช้ความเร็วไม่เกิน 10Mbps

Instant-Hotspot

User Profiles

Add New

User	Profile	State	End Time
BF-4Mg	Day_1	used	2023-07-1
BF-9sF	Day_1	waiting	2106-02-0

วิธีสร้าง Limitations ใหม่

ตัวอย่าง ต้องการกำหนดความเร็ว Download/upload 50Mbps/50Mbps

Name : 50Mbps/50Mbps

1. เลือกเมนู User Manager

2. เลือกแท็บ Limitations

3. Add New

The screenshot shows the Instant-Hotspot web interface. On the left sidebar, the 'User Manager' menu is highlighted with a red box and a circled '1'. At the top, the 'Limitations' tab is selected with a red box and a circled '2'. Below the tabs, the 'Add New' button is highlighted with a red box and a circled '3'. The main content area displays a table with 4 items.

	▲ Name	Download Limit (B)	Upload Limit (B)	Session Limit	Rx Rate Limit	Tx Rate Limit	Rx Rate Limit Burst	Tx Rate Limit Burst
-	10M	0	0	00:00:00	10M	10M	0	0
-	20M	0	0	00:00:00	10M	20M	0	0
-	30M	0	0	00:00:00	30M	30M	0	0
-	Down50M/Up30M	0	0	00:00:00	30M	50M	0	0

The screenshot shows the configuration form for a new limitation. The 'Name' field is filled with '50Mbps/50Mbps' and is highlighted with a red box and a circled '4'. The 'Download/Upload Limit' is set to 0 B / 0 B. The 'Transfer Limit' is 0 B. The 'Session Limit' is 00:00:00. The 'Rx/Tx Rate Limit' is set to 50M / 50M and is highlighted with a red box and a circled '5'. Other fields like 'Rx/Tx Min Rate Limit', 'Rate Limit Priority', 'Rx/Tx Rate Limit Burst', 'Rx/Tx Rate Limit Burst Threshold', 'Rx/Tx Rate Limit Burst Time', 'Reset Counters Start Time', and 'Reset Counters Interval' are also visible. At the bottom, the 'OK' button is highlighted with a red box and a circled '6'.

4. Name: ตั้งชื่อที่ต้องการ

5. Rx/Tx Rate Limit: กำหนดความเร็ว

Rx Rate Limit:

กำหนดความเร็ว Upload (50Mbps)

Tx Rate Limit:

กำหนดความเร็ว Download (50Mbps)

6. กดปุ่ม OK

แสดงผล

The screenshot shows the Instant-Hotspot web interface with the 'Limitations' tab selected. The 'Add New' button is visible. The table now shows 5 items, with the newly added '50Mbps/50Mbps' entry highlighted with a red box.

	▲ Name	Download Limit (B)	Upload Limit (B)	Session Limit	Rx Rate Limit	Tx Rate Limit	Rx Rate Limit Burst	Tx Rate Limit Burst
-	10M	0	0	00:00:00	10M	10M	0	0
-	20M	0	0	00:00:00	10M	20M	0	0
-	30M	0	0	00:00:00	30M	30M	0	0
-	50Mbps/50Mbps	0	0	00:00:00	50M	50M	0	0
-	Down50M/Up30M	0	0	00:00:00	30M	50M	0	0